



# OPERATING YOUR DVR

[ a quick reference guide ]



# With Digital Video Recording from yondoo, you'll never watch TV the same way again.

Watch your favorite programs when it is convenient for you, even live broadcasts. No tapes, timers or VCR required.

## AVAILABLE SERVICES

yondoo's DVR Set-Top-Box has many available services. Simply press the **MENU** button on your remote control to display the menu bar. The menu bar displays services available to you through yondoo. Use the **ARROW KEYS, LEFT AND RIGHT**, to highlight an application then press **OK**.

### INFOBAR

When viewing a program or after selecting its name, in many screens you can press **INFO** to learn more about the item. Press it a second time to view more detailed program descriptions (if available). While in this screen by pressing the arrows **UP** or **DOWN**, you can view adjacent channels. The infobar is updated with information for the displayed channel.

## Viewing Live Programs

### THE GUIDE

To access the Guide, select  on the set top box menu bar and then press **OK**. The guide will show a thumbnail of the current program and program description. The channel listing includes program name and time.

To tune into a channel while in this mode, select the channel, press **OK** to preview the channel while the guide is being displayed. Press **OK** again to tune into the channel.

**Need help?** Call 877.309.4462 or visit [yondoo.com](http://yondoo.com) for assistance.

While the Guide is displayed, you can use the remote to find channels by:

- Entering the **CHANNEL NUMBER** directly using the remote control
- Press the **ARROWS** to scroll through the Guide forward and backward in time
- Press the **ARROWS UP** and **DOWN** to scroll to different channels

## Recording Programs

### LIVE PROGRAMS

To record a program that is presently broadcasting

- Open the **GUIDE** function
- Then, select the program you want to record, then press **RECORD (REC)** on the remote control

The  red dot appears next to the program to note the program is being recorded.

### SCHEDULE A RECORDING

To schedule a recording for a single program or episode that starts in the future

- Open the **GUIDE** function
- Then, select the program you want to record, press **OK**. A list of options will appear
- Select **RECORD PROGRAM**, then press **OK**. The options will close and the record icon  appears next to the program

### SCHEDULING A SERIES

The set-top box can recognize programs as being part of a series. To schedule the recording of program episodes that your STB recognizes

- Open the **GUIDE** function
- Then, select the program you want to record, press **OK**. A list of options will appear

- Select **RECORD SERIES**, then press **OK**. A list of options will appear to include settings for **CHANNELS, PREFERENCES, EPISODES, START, END AND LIMIT TO VALUES**
- Select the default value of each setting you want to change, press **OK**. Use the up and down arrows to scroll between the values. Press **OK** to accept the value
- When all settings are in place, select **OK**, then press **OK**. The series is now scheduled to record

## Viewing and Managing Recordings

### VIEWING A RECORDING

Press the **MENU** button to display the menu bar.

- Open the **DVR**  function
- Then, select **RECORDINGS**
- Press the arrow to move to the windowpane showing all recorded programs
- The recorded programs can be sorted by **DATE, TITLE, CHANNEL, VIEWED/NOT**. Select one of the sort options then press **OK**. Select the program you want to watch, then press **OK**
- Select **PLAY RECORDING**

### DELETING A RECORDING

To delete a recording:

- Open the **DVR** function and select **RECORDINGS**
- Press the arrow to move to the pane showing all recorded programs
- Then, select the program you want to delete, press **OK**
- Select **DELETE** Recording, then press **OK**. (Note: If you select recordings from a series, the Delete All option appears)
- You can still **DELETE** a single recording or **DELETE** all.

# Using Your Remote

## PAUSE

While watching live broadcasts or recorded programming, press **PAUSE**  to instantly freeze the scene. Press **PLAY**  to return to normal play of the program.

## REWIND

To review a portion of the program you are viewing, press **REWIND** . Continually press rewind to increase the rewind speed up to 4 times. A fifth press will resume normal play.

## INSTANT REPLAY

To replay the last 7 seconds of a program, press **REPLAY** . Press repeatedly to continue skipping back in 7 second intervals.



## SLOW MOTION

To activate slow-forward, press **PAUSE**  and then **FAST FORWARD** .

To use slow-rewind, press **PAUSE**  and then **REWIND** . Press **PLAY**  to return to regular speed.

## ONE TOUCH RECORDING

Simply press **RECORD**  on your remote and the recording process will begin immediately for programs currently airing.

## FAST FORWARD

Press **FAST FORWARD**  to move forward during recorded programs. Continually press to increase the fast forward speed. A fifth press will resume normal play. You must press play to resume normal play.

## RETURN TO LIVE TV

To return to the live broadcast press the **live**  button.

**Need help?** Call 877.309.4462 or visit [yondoo.com](http://yondoo.com) for assistance.

# My Account Information

## ACCOUNT NUMBER

You can find your account number on the receipt given to you at the yondoo Service Center or at the top right corner of your most recent bill.

Account Number \_\_\_\_\_

Phone Number \_\_\_\_\_

## DEVICE INFORMATION

Set Top Box Locations \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

NOTES \_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

**For more information** or to retrieve your account information, please call 888.888.8888 or visit [yondoo.com](http://yondoo.com)



[yondoo.com](http://yondoo.com) | 877.309.4462